

baby lock

Plain Hemmer

1/2 inch (13mm) Item No: B0421S06A-E (BLE8-S6)

Stitches Used:

Chain Stitch - C1 needle position
Narrow Left Cover Stitch - C1 - C2
needle positions
Wide Cover Stitch-C1-C3
Triple Cover Stitch-C1-C2-C3

Sewing Speed: Moderate to slow.

Fabrics:

Firm broadcloth, trigger, lt. wt. denim,
lt. wt. polar fleece*, sweatshirt fleece*.

INSTRUCTIONS:

Stitch Length: 3-4

Cutting Blade: Disengaged "LOCKED"

Upper Looper: Down

Sewing Table: On

Straight Hemming ONLY. Leave one seam of garment open. After hemming, sew seam closed.

1. Secure attachment to table with guide fixing screws.
2. Turn under 1/2 inch and press with iron.
3. Raise presser foot. Slide fabric into attachment with wrong side facing up, turning up and over to the left.
4. With a sewing awl, slide folded fabric under presser foot to the needle.
5. Lower the presser foot. Turn the hand wheel 3-4 times to secure the fabric.
6. Align the attachment with the needle(s) to encase the fabric edge.
7. With right hand keep hem turned while left hand is guiding folded fabric into hemmer.

NOTE: When hemming polar fleece or sweatshirt fleece, turn fabric one time.
Do not attempt a double roll. (fabric does not ravel)

