

Plain Hemmer

Item No: B0421S06A 1/2 inch (13mm)

Stitches Used:

Chain Stitch - C1 needle position Narrow Left Cover Stitch - C1 - C2 needle positions Wide Cover Stitch-C1-C3 Triple Cover Stitch-C1-C2-C3

Straight Hemming ONLY. Leave one seam of garment open. After hemming, sew seam closed.

Available for:

BLES8W-2, BLE5-3, BLCS

Sewing Speed: Moderate to slow.

Fabrics:

Firm broadcloth, trigger, It. wt. denim, It. wt. polar fleece*, sweatshirt fleece*.

INSTRUCTIONS:

Stitch Length: 3-4

Cutting Blade: Disengaged "LOCKED"

Upper Looper: Down Sewing Table: On

- 1. Secure attachment to table with guide fixing screws.
- 2. Turn under 1/2 inch and press with iron.
- 3. Raise presser foot. Slide fabric into attachment with wrong side facing up, turning up and over to the left.
- 4. With a sewing awl, slide folded fabric under presser foot to the needle.
- 5. Lower the presser foot. Turn the hand wheel 3-4 times to secure the fabric.
- 6. Align the attachment with the needle(s) to encase the fabric edge.
- 7. With right hand keep hem turned while left hand is guiding folded fabric into hemmer.

NOTE: When hemming polar fleece or sweatshirt fleece, turn fabric one time. Do not attempt a double roll. (fabric does not ravel)

